

Ghid de Utilizare pentru Centrala Adresabila de Alarma Incendiu iRIS8

Eveniment INCENDIU in Sistem

Indicatie ALARMA INCENDIU

Sirene Activate

Mesaj ALARMA INCENDIU

Zone cu ALARMA INCENDIU

The interface displays a status bar with 'INCENDIU GENERAL' (General Fire) and 'Sirene Activate' (Sirens Activated). Below this, a grid of 36 zones is shown, with zones 1, 2, and 3 highlighted in red. A message box at the top right shows 'Evacuati, Zona 1, Bucla 1, Adresa dispozitivului de bucla 7' (Evacuate, Zone 1, Loop 1, Device address of loop 7) and a time of 09:42 on 13.07.2021. The bottom bar shows '1 Alarme' (1 Alarm), '0 Defectiuni' (0 Faults), and '0 Avertismente' (0 Warnings).

1 Eveniment ALARMA INCENDIU, temporizare programata pentru Sirene, iesiri Incendiu si Protectie Incendiu Opriți soneria din centrala:

The interface displays a status bar with 'Alarma, Zona 1, Bucla 1, Adresa dispozitivului de bucla 5' (Alarm, Zone 1, Loop 1, Device address of loop 5) and a time of 09:42 on 13.07.2021. The bottom bar shows '1 Alarme' (1 Alarm), '0 Defectiuni' (0 Faults), and '0 Avertismente' (0 Warnings). A red box highlights the 'MENU' button.

In caz de Operare in Retea, opriti soneria din centrala astfel:

The interface displays a status bar with 'Evacuati, Zona 1, Bucla 1, Adresa dispozitivului de bucla 7' (Evacuate, Zone 1, Loop 1, Device address of loop 7) and a time of 09:43 on 13.07.2021. The bottom bar shows '1 Alarme' (1 Alarm), '0 Defectiuni' (0 Faults), and '0 Avertismente' (0 Warnings). A red box highlights the 'MENU' button.

The interface displays a status bar with 'Alarma, Zona 1, Bucla 1, Adresa dispozitivului de bucla 5' (Alarm, Zone 1, Loop 1, Device address of loop 5) and a time of 09:43 on 13.07.2021. The bottom bar shows '1 Alarme' (1 Alarm), '0 Defectiuni' (0 Faults), and '0 Avertismente' (0 Warnings). A red box highlights the '1 Alarme' button.

Mergeti in zona cu eveniment de alarma incendiu si verificati daca exista un INCENDIU adevarat, apoi urmati
Etapa 2 - Start Evacuare,
si/sau
Etapa 3 - Stop Sirene,
in functie de situatie.

2 ALARMA INCENDIU adevarata, temporizare programata pentru Sirene, iesiri Incendiu si Protectie Incendiu Start Evacuare:

The interface displays a status bar with 'Alarma, Zona 1, Bucla 1, Adresa dispozitivului de bucla 5' (Alarm, Zone 1, Loop 1, Device address of loop 5) and a time of 09:43 on 13.07.2021. The bottom bar shows '1 Alarme' (1 Alarm), '0 Defectiuni' (0 Faults), and '0 Avertismente' (0 Warnings). A red box highlights the 'MENU' button.

In caz de Operare in Retea, startul Evacuarii se face astfel:

The interface displays a status bar with 'Evacuati, Zona 1, Bucla 1, Adresa dispozitivului de bucla 7' (Evacuate, Zone 1, Loop 1, Device address of loop 7) and a time of 09:43 on 13.07.2021. The bottom bar shows '1 Alarme' (1 Alarm), '0 Defectiuni' (0 Faults), and '0 Avertismente' (0 Warnings). A red box highlights the 'MENU' button.

Sirene Active → **112**

3 Opriti sirenele si Reporniti:

The interface displays a status bar with 'Evacuati, Zona 1, Bucla 1, Adresa dispozitivului de bucla 7' (Evacuate, Zone 1, Loop 1, Device address of loop 7) and a time of 09:43 on 13.07.2021. The bottom bar shows '1 Alarme' (1 Alarm), '0 Defectiuni' (0 Faults), and '0 Avertismente' (0 Warnings). A red box highlights the 'Accesati 1' button.

The interface displays a status bar with 'Evacuati, Zona 1, Bucla 1, Adresa dispozitivului de bucla 7' (Evacuate, Zone 1, Loop 1, Device address of loop 7) and a time of 09:43 on 13.07.2021. The bottom bar shows '1 Alarme' (1 Alarm), '0 Defectiuni' (0 Faults), and '0 Avertismente' (0 Warnings). A red box highlights the 'Accesati 2' button.

In caz de Operare in Retea, alegeti centralele unde vreti sa se opreasca sirenele.

Centrala este repornita in modul de operare Normal.

Apasati **Accesati 2**, apoi **LOG OUT**.